

The attenuator reduces the level of received signals. It is useful when there is strong interference from an adjacent frequency. Since the main transceiver and sub-receiver share the same antenna for the 144 and 430/440 Mhz bands, activating the attenuator function for the sub-receiver also causes the function to switch on for the same band of the main transceiver.

Dämparen minskar nivån av mottagna signaler. Detta är användbart när det finns en stark interferens från en närliggande frekvens. Eftersom huvud transceiver och sub-mottagare delar samma antenn för 144 och 430/440 MHz-banden, aktivera dämpningsfunktionen för sub-mottagare orsakar också funktionen att slå på i samma grupp av huvud transceiver.